

Assembly Instructions



ergoCentric[®]

The science of sitting*

Parts




Assembly Instructions

Step 1:


For tables using 1 High Pressure Laminate (HPL) panel

a) Lay the HPL tabletop panel face down on the floor, with the brown backer facing up.



For tables using 2 or more HPL panels

b) Align the HPL tabletop panels together face down, and secure them using the #10x%" wood screws (A) and tabletop plates (B).




Step 2:


For tables using 2 or more HPL panels

a) Lay the plywood panels on top of the HPL panels, with the brown backer facing up.


2-piece tabletop



3-piece tabletop



4-piece tabletop




Step 3:

a) Use #10x%" wood screws **(A)** to attach the under-table supports **(H)** to the brown backer surface.


For tables using 2 or more plywood panels

b) Use M6x20 screws **(C)** for the two holes at each end, and for the four holes on either side of each seam.


1-piece tabletop



3-piece tabletop



4-piece tabletop




Step 4:


For tables using 2 or more HPL panels. Skip this step if there is no plywood.

a) Secure the plywood to the HPL panels using #8x1.5" wood screws **(D)** through the holes highlighted below


2-piece tabletop



3-piece tabletop



4-piece tabletop




Step 5:


This step shows two assembly options based on the number of legs to be installed. Users should follow the instructions for their specific configuration.

For tables using only 2 Legs

a) Slide Mounting Bracket **(R)** on to the motor housings of the legs **(J)** and install with 4x M6x16 Panhead Screws **(E)**.




b) Attach the X feet **(L)** to the ends of the legs **(J)** with 4x M10 bolts **(F)**.




For tables using 4 Legs

a) Install 2x Leg Attachment Brackets (I) on the motor housings of the legs (J) with 4x M6x16 Panhead Screws (E).



b) Attach the post feet **(K)** and X feet **(L)** to the ends of the legs **(J)** with 4x M10 bolts **(F)** each.




Step 6:

If installing leg assemblies directly to the HPL panels,


a) Use #10x7/8" wood screws (A) and align with pilot holes.

If installing leg assemblies to the plywood panels

b) Use 4x M6x20 screws **(C)** and 4x 10x%" wood screws **(A)** onto the plywood, aligning with threaded inserts and pilot holes.




Step 7:



- a) Attach the control box(es) (M) using #10x%" wood screws (A).
- b) Attach the handset **(N)** using 2x flathead wood screws **(G)** aligning with pilot holes located along the edges of the HPL panels.


c) Connect wires from legs (J), handset wire (N) and power cable (P) to control box.

2 Leg Tables



When installing two control boxes, connect the handset wire **(N)** to the Y-Splitter cable **(O)**, and connect both ends of the Y Splitter Cable to both control boxes.

4 Leg Tables



d) Secure all wires with wire clips (Q) and fasten them to the table using #10x%" wood screws (A).

Step 8:

Install any mountable power bars, cable management baskets, and other under-table accessories using the instructions provided with the accessories.

Step 9:

Carefully turn the table over to its up right position, and move table into the desired location.




Step 10:

- a) Plug table into power and perform a reset Press and hold ♠ and ♠ button until table reaches lowest position.
 Continue holding for 10 seconds after reaching lowest position, or
 until you hear an additional beep.
- b) Test the parallel connectivity by pressing button for 3 seconds to adjust table upwards. If all 4 legs do not rise together, check Y connector and perform a reset again.
- c) Once all legs are rising together, use leveling glides on feet to level table.

Step 11:

For tables using 2 or more HPL panels

Adjust the alignment of the tabletop panels by loosening or tightening the screws along the tabletop seams.



Step 12:

Finally, install any top-mounted power/data port docks and secure the wires under the table using the supplied wire clips **(Q)**

ergoCentric^{*}

ph: 1 866 GET ERGO (438-3746) | 905 696-6800 service@ergocentric.com ergocentric.com